

Sauna controller UKU extension box

The following scheme is used to connect the heater over 9 kW. (Hive 12, 15 and 18 kW. Fix the unit to the wall with 4 screws.

Placement

The extension box has to be located outside the steam room, near UKU main module.

